


CHARGING YOUR ACP39x STEP-by-STEP



1. FULLY OPEN AND CLOSE PUMP FOREARM IN A NORMAL PUMP STROKE.

2. RELAX HAND PRESSURE ON FOREARM. CHECK PRESSURE TELLTALE SCREW HEAD.

3. IF TELLTALE IS FULLY SEATED AGAINST WOOD, (A) VALVE ISN'T FULLY PRESSURIZED YET. CONTINUE PUMPING AT STEP #1.

4. IF A GAP EXISTS (B) BETWEEN TELLTALE AND WOOD - NO MATTER HOW SMALL - PRESSURE IS AT FULL. STOP PUMPING.

5. TUG LIGHTLY ON FOREARM TO RESEAT TELLTALE AGAINST WOOD BEFORE SHOOTING.